



SY-5EHM/5EH5

**Super 7™
Motherboard**

Quick Start Guide

Introduction

Installation

Quick BIOS Setup

The SOYO CD

FC Tested To Comply
With FCC Standards
FOR HOME OR OFFICE USE

100% POST CONSUMER
RECYCLED PAPER

5EHM/5EH5 Super 7™ Motherboard

Pentium® Class CPU (66&100MHz) supported
ETEQ82C663 PCI/AGP Motherboard
AT Form Factor

Copyright © 1998 by Soyo Computer Inc.

Trademarks:

Soyo is a registered trademark of Soyo Computer Inc. All trademarks are the property of their owners.

Product Rights:

Product and corporate names mentioned in this publication are used for identification purposes only and may be registered trademarks or copyrights of their respective companies.

Copyright Notice:

All rights reserved. This manual is copyrighted by Soyo Computer Inc. You may not reproduce, transmit, transcribe, store in a retrieval system, or translate into any language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, any part of this publication without express written permission of Soyo Computer Inc.

Disclaimer:

Soyo Computer Inc. makes no representations or warranties regarding the contents of this manual. We reserve the right to revise the manual or make changes in the specifications of the product described within it at any time without notice and without obligation to notify any person of such revision or change. The information contained in this manual is provided for general use by our customers. Our customers should be aware that the personal computer field is the subject of many patents. Our customers should ensure that their use of our products does not infringe upon any patents. It is the policy of Soyo Computer Inc. to respect the valid patent rights of third parties and not to infringe upon or assist others to infringe upon such rights.

Restricted Rights Legend:

Use, duplication, or disclosure by the Government is subject to restrictions set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at 252.277-7013.

About This Guide:

This Quick Start Guide is for assisting system manufacturers and end users in setting up and installing the Motherboard. Information in this guide has been carefully checked for reliability; however, no guarantee is given as to the correctness of the contents. The information in this document is subject to change without notice.

If you need any further information, please visit our **Web Site** on the Internet. The address is "<http://www.soyo.com.tw>".

5EHM/5EH5 Serial - Version 2.2 - Edition: July 1999

* These specifications are subject to change without notice

1 Introduction


Congratulations on your purchase of the **5EHM/5EH5** Super 7™ Motherboard. This *Quick Start Guide* describes the steps for installing and setting up your new Motherboard.

This guide is designed for all users to provide the basic steps of Motherboard setting and operation. For further information, please refer to *5EHM/5EH5 Motherboard User's Guide and Technical Reference* online manual included on the CD-ROM packed with your Motherboard.

Unpacking


When unpacking the Motherboard, check for the following items:

- ◆ The 5EHM/5EH5 Super 7™ Motherboard
- ◆ The Quick Start Guide
- ◆ The Installation CD-ROM
- ◆ One IDE Device Flat Cable
- ◆ One Floppy Disk Drive Flat Cable
- ◆ One 9-pin serial connector with 9-pin flat cable and 6-pin PS/2 mouse connector with 6-pin cable
- ◆ One 25-pin parallel connector with 25-pin flat cable and 9-pin serial connector with 9-pin flat cable



SY-5EHM/5EH5 Quick Start Guide

SY-5EHM/5EH5 Motherboard Layout



- 100MHz AGP Super 7™ platform
- 512KByte/1MByte L2 cache
- Supports CPU voltage from 2.0V to 3.5V in 0.1V increments
- PC97, ACPI, Ultra DMA/33MHz
- Power-on by modem or alarm
- Supports AT or ATX power connector
- Supports Wake-On-LAN (WOL)
- Fan off in suspend mode
- 3 x 32-bit bus mastering PCI slots
- 1 x IrDA port
- Supports multiple-boot function
- DMI utility

2 Installation



To avoid damage to your Motherboard, follow these simple rules while handling this equipment:

- Before handling the Motherboard, ground yourself by grasping an unpainted portion of the system's metal chassis.
- Remove the Motherboard from its anti-static packaging. Hold it by the edges and avoid touching its components.
- Check the Motherboard for damage. If any chip appears loose, press carefully to seat it firmly in its socket.

Follow the directions in this section designed to guide you through a quick and correct installation of your new **5EHM/5EH5** Super 7™ Motherboard. For detailed information, please refer to *5EHM/5EH5 Motherboard User's guide and Technical Reference* online manual included on the CD-ROM packed with your Motherboard.

PREPARATIONS

Gather and prepare all the necessary hardware equipment to complete the installation successfully:

- ◆ Pentium® Class processor with cooling fan
- ◆ SDRAM module
- ◆ Computer case and chassis with adequate power supply unit
- ◆ Monitor
- ◆ Keyboard
- ◆ Pointing Device (PS/2 mouse)
- ◆ VGA Card
- ◆ Sound Card (optional)
- ◆ Speaker(s) (optional)
- ◆ Disk Drives: HDD, CD-ROM, Floppy drive ...
- ◆ External Peripherals: Printer, Plotter, and Modem- (optional)

SY-5EHM/5EH5 Quick Start Guide


Install the Motherboard

Follow the steps below in order to perform the installation of your new **5EHM/5EH5** Super 7™ Motherboard.

Step 1. Install the CPU

To mount the Pentium® processor that you have purchased separately, follow these instructions.

CPU Mount Procedure



1. Lift the socket handle up to a vertical position.
2. Align the blunt edge of the CPU with the matching pinhole distinctive edge on the socket.
3. Seat the processor in the socket completely and without forcing.
4. Then close the socket handle to secure the CPU in place.



Remember to connect the CPU Cooling Fan to the appropriate power connector (JP12) on the Motherboard. *The fan is a key component that will ensure system stability. The fan prevents overheating, therefore prolonging the life of your CPU.*

SY-5EHM/5EH5 Quick Start Guide

Step 2. Set JP30 for CPU Voltage

This Motherboard features the **Smart Detect CPU Voltage** function which is designed to automatically detect the voltage of the CPU. If you install any of the following CPUs, the voltage adjustment is automatic: Intel® P54C, Intel® P55C, AMD™ K5, or Cyrix™ 6x86/L.

For other CPUs that come with different voltages, please verify the correct voltage settings with your dealer before installation. Use the following table to set JP30 to the proper voltage value, according to the specifications marked on your CPU:

| Processor | Voltage | Voltage Setting: JP30 | | | | | |
|--|--|-----------------------|-------|-------|-------|-------|-------|
| | | 1-2 | 3-4 | 5-6 | 7-8 | 9-10 | 11-12 |
| AMD K5 PR100 AMD K5 PR133 AMD K5 PR166 | 3.52 V | close | open | open | open | open | close |
| | The AMD K5 and K6 come in several versions with different voltages. Please verify the correct voltage settings with your dealer before installation. The most common K5 runs on 3.52V. | | | | | | |
| AMD K6 166 AMD K6 200 | 2.9 V | close | open | close | open | open | open |
| AMD K6 233 | 3.2 V | close | open | open | close | open | open |
| AMD K6 266 AMD K6 300 AMD K6-2 266 AMD K6-2 300 AMD K6-2 333 AMD K6-2 350 AMD K6-2 366 AMD K6-2 400 AMD K6-2 500 | 2.2 V | open | close | open | open | close | open |
| AMD K6-2 450 | 2.2 V | open | close | open | open | close | open |
| AMD K6-2 475 | 2.4 V | open | open | open | close | close | open |
| AMD K6-III 400 AMD K6-III 450 | The AMD K6-2 and K6-III comes in several versions with different voltages. Please ask your dealer for the correct voltage. | | | | | | |
| Cyrix 6x86(L) PR166+ Cyrix 6x86(L) PR200+ | The Cyrix 6X86(L) and MII come in several versions with different voltages. Please ask your dealer for the correct voltage. | | | | | | |
| Cyrix 6x86MX PR166 Cyrix 6x86MX PR200 Cyrix 6x86MX PR233 Cyrix 6x86MX PR266 Cyrix MII 300 Cyrix MII 333 Cyrix MII 350 Cyrix MII 366 | 2.9 V | close | open | close | open | open | open |
| Intel P54C P100 | 3.3 V | close | open | open | open | close | open |
| Intel P54C P133 Intel P54C P166 Intel P54C P200 | The P54C (standard Pentium®) comes in several versions with different voltages. Please ask your dealer for the correct voltage. The most common P54C runs on 3.3V. | | | | | | |
| Intel P55C P166 Intel P55C P200 | 2.8 V | close | open | open | open | open | close |
| Intel P55C P233 | The P55C (MMX) processors have the same voltage setting. | | | | | | |

SY-5EHM/5EH5 Quick Start Guide

| Processor | Voltage | Voltage Setting: JP30 | | | | | |
|---|---------|-----------------------|------|------|------|-------|-------|
| | | 1-2 | 3-4 | 5-6 | 7-8 | 9-10 | 11-12 |
| IDT WinChip C6/2-225 IDT WinChip 2-266 | 3.52V | close | open | open | open | open | close |
| IDT WinChip C6/2-200 IDT WinChip 2-233 | 3.3 V | close | open | open | open | close | open |
| Rise mP6 PR266 | 2.8 V | close | open | open | open | open | close |

Step 3. Set SW1 for CPU Frequency

The DIP switch SW1 enables you to assign the Frequency Multiplier, CPU Host Bus Clock, AGP Clock and PCI Clock, as shown in the following table:

| Processor | Multiplier | CPU Bus Clock | JP7 | JP9 | JP10 | Frequency Setting: SW1 | | | | | |
|-----------------------|------------|---------------|-----|-----|------|------------------------|-----|-----|-----|-----|-----|
| | | | | | | 1 | 2 | 3 | 4 | 5 | 6 |
| AMD K5 PR100 | 1.5x | 66MHz | 2-3 | 2-3 | 1-2 | off | off | off | off | off | off |
| AMD K5 PR133 | 2.0x | 66MHz | 2-3 | 2-3 | 1-2 | on | off | off | off | off | off |
| AMD K5 PR166 | 2.5x | 66MHz | 2-3 | 2-3 | 1-2 | on | on | off | off | off | off |
| AMD K6 166 | 2.5x | 66MHz | 2-3 | 2-3 | 1-2 | on | on | off | off | off | off |
| AMD K6 200 | 3x | 66MHz | 2-3 | 2-3 | 1-2 | off | on | off | off | off | off |
| AMD K6 233 | 3.5x | 66MHz | 2-3 | 2-3 | 1-2 | off | off | off | off | off | off |
| AMD K6 266 | 4.0x | 66MHz | 2-3 | 2-3 | 1-2 | on | off | on | off | off | off |
| AMD K6 300 | 4.5x | 66MHz | 2-3 | 2-3 | 1-2 | on | on | on | off | off | off |
| AMD K6-2 266 | 4.0x | 66MHz | 2-3 | 2-3 | 1-2 | on | off | on | off | off | off |
| AMD K6-2 300 | 4.5x | 66MHz | 2-3 | 2-3 | 1-2 | on | on | on | off | off | off |
| | 3x | 100MHz | 1-2 | 2-3 | 1-2 | off | on | off | off | off | on |
| AMD K6-2 333 | 5.0x | 66MHz | 2-3 | 2-3 | 1-2 | off | on | on | off | off | off |
| | 3.5x | 95MHz | 1-2 | 2-3 | 1-2 | off | off | off | on | off | on |
| AMD K6-2 350 | 3.5x | 100MHz | 1-2 | 2-3 | 1-2 | off | off | off | off | off | on |
| AMD K6-2 366 | 5.5x | 66MHz | 2-3 | 2-3 | 1-2 | off | off | on | off | off | off |
| AMD K6-2 380 | 4.0x | 95MHz | 1-2 | 2-3 | 1-2 | on | off | on | on | off | on |
| AMD K6-2 400 | 4.0x | 100MHz | 1-2 | 2-3 | 1-2 | on | off | on | off | off | on |
| AMD K6-2 450 | 4.5x | 100MHz | 1-2 | 2-3 | 1-2 | on | on | on | off | off | on |
| AMD K6-2 475 | 5.0x | 95MHz | 1-2 | 2-3 | 1-2 | off | on | on | on | off | on |
| AMD K6-2 500 | 5.0x | 100MHz | 1-2 | 2-3 | 1-2 | off | on | on | off | off | on |
| AMD K6-III 400 | 4.0x | 100MHz | 1-2 | 2-3 | 1-2 | on | off | on | off | off | on |
| AMD K6-III 450 | 4.5x | 100MHz | 1-2 | 2-3 | 1-2 | on | on | on | off | off | on |
| Cyrix 6x86 MX PR 166+ | 2.0x | 66MHz | 2-3 | 2-3 | 1-2 | on | off | off | off | off | off |
| Cyrix 6x86 PR MX 200+ | 2.0x | 75MHz | 2-3 | 2-3 | 1-2 | on | off | off | off | on | off |
| Cyrix 6x86 MX PR 166 | 2.0x | 66MHz | 2-3 | 2-3 | 1-2 | on | off | off | off | off | off |
| Cyrix 6x86 MX PR 200 | 2.5x | 66MHz | 2-3 | 2-3 | 1-2 | on | on | off | off | off | off |
| | 2.0x | 75MHz | 2-3 | 2-3 | 1-2 | on | off | off | off | on | off |
| Cyrix 6x86 MX PR 233 | 2.5x | 75MHz | 2-3 | 2-3 | 1-2 | on | on | off | off | on | off |

SY-5EHM/5EH5 Quick Start Guide

| Processor | Multiplier | CPU Bus Clock | JP7 | JP9 | JP10 | Frequency Setting: SW1 | | | | | |
|----------------------|------------|---------------|-----|-----|------|------------------------|-----|-----|-----|-----|-----|
| | | | | | | 1 | 2 | 3 | 4 | 5 | 6 |
| Cyrix 6x86 MX PR 266 | 2.5x | 83MHz | 1-2 | 2-3 | 1-2 | on | on | off | on | on | off |
| Cyrix MII 300 | 3.5x | 66MHz | 2-3 | 2-3 | 1-2 | off | off | off | off | off | off |
| | 3x | 75MHz | 2-3 | 2-3 | 1-2 | off | on | off | off | on | off |
| Cyrix MII 333 | 4.0x | 66MHz | 2-3 | 2-3 | 1-2 | on | off | on | off | off | off |
| | 3.5x | 75MHz | 2-3 | 2-3 | 1-2 | off | off | off | off | on | off |
| | 3x | 83MHz | 1-2 | 2-3 | 1-2 | off | on | off | on | on | off |
| | 2.5x | 100MHz | 1-2 | 2-3 | 1-2 | on | on | off | off | off | on |
| Cyrix MII 350 | 3x | 100MHz | 1-2 | 2-3 | 1-2 | off | on | off | off | off | on |
| Cyrix MII 366 | 2.5x | 100MHz | 1-2 | 2-3 | 1-2 | on | on | off | off | off | on |
| P54C P100 | 1.5x | 66MHz | 2-3 | 2-3 | 1-2 | off | off | off | off | off | off |
| P54C P133 | 2.0x | 66MHz | 2-3 | 2-3 | 1-2 | on | off | off | off | off | off |
| P54C/P55C P166 | 2.5x | 66MHz | 2-3 | 2-3 | 1-2 | on | on | off | off | off | off |
| P54C/P55C P200 | 3x | 66MHz | 2-3 | 2-3 | 1-2 | off | on | off | off | off | off |
| P55C P233 | 3.5x | 66MHz | 2-3 | 2-3 | 1-2 | off | off | off | off | off | off |
| IDT WinChip C6/2-200 | 3x | 66MHz | 2-3 | 2-3 | 1-2 | off | on | off | off | off | off |
| IDT WinChip C6/2-225 | 3x | 75MHz | 2-3 | 2-3 | 1-2 | off | on | off | off | on | off |
| IDT WinChip 2-233 | 3.5x | 66MHz | 2-3 | 2-3 | 1-2 | off | off | off | off | off | off |
| IDT WinChip 2-266 | 2.33x | 100MHz | 1-2 | 1-2 | 2-3 | off | on | on | off | off | on |
| Rise mP6 PR266 | 3x | 66MHz | 2-3 | 2-3 | 1-2 | off | on | off | off | off | off |
| | 2x | 100MHz | 1-2 | 1-2 | 2-3 | on | off | off | off | off | on |

This main board supports various CPU multiplier and host bus frequency settings. Please select the proper frequency setting based on specifications of the CPU you have purchased. System stability or components damage, in case of over-specification setting, is not guaranteed.

Jumper JP7 is used to indicate the frequency of the CPU bus clock to the ETEQ chipset. Jumpers JP9 and JP10 are used to determine that the SDRAM is running at the frequency of the CPU bus clock or at that of the AGP clock.

| CPU BUS Clock | AGP BUS Clock | PCI Clock | JP7 | JP9 | JP10 | SDRAM Clock |
|---------------|---------------|-----------|-----|-----|------|-------------|
| 66MHz | 66MHz | 33MHz | 2-3 | 2-3 | 1-2 | 66MHz |
| 75MHz | 75MHz | 37.5MHz | 2-3 | 2-3 | 1-2 | 75MHz |
| 83MHz | 55MHz | 27.5MHz | 1-2 | 1-2 | 2-3 | 55MHz |
| | | | 1-2 | 2-3 | 1-2 | 83MHz |
| 95MHz | 63.4MHz | 31.7MHz | 1-2 | 1-2 | 2-3 | 63.4MHz |
| | | | 1-2 | 2-3 | 1-2 | 95MHz |
| 100MHz | 66MHz | 33MHz | 1-2 | 1-2 | 2-3 | 66MHz |
| | | | 1-2 | 2-3 | 1-2 | 100MHz |
| 112MHz | 75MHz | 37.5MHz | 1-2 | 1-2 | 2-3 | 75MHz |
| | | | 1-2 | 2-3 | 1-2 | 112MHz |
| 124MHz | 82.6MHz | 41.3MHz | 1-2 | 1-2 | 2-3 | 82.6MHz |
| | | | 1-2 | 2-3 | 1-2 | 124MHz |



SY-5EHM/5EH5 Quick Start Guide

Note: Use 8ns or faster SDRAM modules (for PC100) when SDRAM is set to run at the frequency of 95/100MHz.

Step 4. Select the CPU Burst Mode

There are two types of CPU burst modes according to manufacturer design:

- Interleave Burst (CPU: Intel P54C/P55C, AMD K5/K6/K6-2/K6-III, IDT WinChip)
- Linear Burst (CPU: Cyrix 6x86/L/MX/MII)

| CPU Burst Mode | Interleave | | Linear | |
|---------------------|---|---|-------------------------------|---|
| | Intel® P54C/P55C AMD™ K5/K6/K6-2/K6-III, IDT WinChip | | Cyrix™ 6x86/L/MX/MII | |
| JP22 Setting | When using Intel or AMD CPUs. (Default) |  | When using Cyrix type of CPU. |  |



If you are using a Cyrix™ 6x86/L/MX/M II series CPU, set the burst mode to Linear by shorting pin 2-3 on jumper JP22, and follow the following steps to select the correct Linear burst mode in BIOS:

1. During the boot-up initial sequence, press the [Delete] key to enter the BIOS setup menu.
2. Select the [CHIPSET FEATURES SETUP] section in BIOS.
3. In the [CHIPSET FEATURES SETUP] sub-menu, set the [Linear Burst] field to [Enabled].
4. Press [Esc] to return to the BIOS main menu.
5. Then choose [Save & Exit Setup] to re-boot your computer.

Step 5. Adjust the DIMM Voltage

There are two kinds of DIMM voltages on the market: 3.3V and 5V.

Most SDRAM DIMMs on the market feature a voltage value of 3.3V. Set JP37 to the correct voltage value according to the DIMM modules that you are using.

| DIMM Voltage | 3.3V | 5V Check DIMM voltage carefully before setting the jumper |
|---------------------|---|---|
| JP37 Setting |  |  |

Step 6. Attach Connectors

This section tells how to connect internal peripherals and power supply to the Motherboard.

Internal peripherals include IDE devices (HDD, CD-ROM), Floppy Disk Drive, Front Panel Devices (Turbo LED, Internal Speaker, Reset Button, IDE LED, and KeyLock Switch.), Wake-On-LAN card, VGA card, Sound Card, and other devices.

For more details on how to connect internal and external peripherals to your new 5EHM/5EH5 Super 7™ Motherboard, please refer to *5EHM/5EH5 Motherboard User's Guide and Technical Reference* online manual on CD-ROM.

Connectors and Plug-ins

| IRDA (Infrared Device Header): IR1 | | | | | Wake-On-LAN Header: JP44 | | | |
|---|-------------|-----------|--|--------------|--------------------------|------------|-------------|------|
| Pin1 | Pin2 | Pin3 | Pin4 | Pin5 | Pin1 | Pin2 | Pin3 | |
| VCC | None | IRRX | GND | IRTX | 5VSB | GND | MP-Wakeup | |
| CPU Cooling Fan: JP12 | | | | USB | | | | |
| Pin1 | Pin2 | Pin3 | Connect your USB devices to this header. | | | | | |
| GND | 12V | NC | | | | | | |
| | | | | Power LED | | Keylock | | |
| | | | | Pin1 | Pin2 | Pin3 | Pin1 | Pin2 |
| | | | | 5V | NC | GND | Control Pin | GND |
| | | | | Speaker | | | | |
| Pin1 | Pin2 | Pin3 | Pin4 | 5V | NC | NC | Speaker out | |
| HDD LED | | TB LED | | PWRBT | | RESET | | |
| Pin1 | Pin2 | Pin1 | Pin2 | Pin1 | Pin2 | Pin1 | Pin2 | |
| LED Anode | LED Cathode | LED Anode | LED Cathode | Power On/Off | GND | Power Good | GND | |
| ATX Power On/Off: PWRBT | | | | | | | | |
| Connect your power switch to this header (momentary switch type). To turn off the system, please press this switch and hold down for longer than 4 seconds. | | | | | | | | |
| AT Power Cable | | | ATX Power Supply: ATX PW | | | | | |
| Connect the AT Power cable to this connector. If you use AT power supply. | | | Attach the ATX Power cable to this connector. If you use ATX power supply. Please make sure the ATX power supply can take at least 720mA load on the 5V standby lead (5VSB), if you want to use the advanced power management function like Power-On by modem or WOL. | | | | | |

SY-5EHM/5EH5 Quick Start Guide

Step 7. Configure Memory

Your board comes with one SIMM Bank (2 modules) and two DIMM sockets, providing support for up to 512MB of main memory using DIMM modules from 8MB to 256MB. For 66MHz host bus CPUs use 12ns or faster DIMM modules; for 83MHz host bus CPUs use 8ns modules.



Memory Configuration Table

| MEMORY CONFIGURATION | SIMM Bank | DIMM Banks | |
|-----------------------------|--------------|--------------------|--------------------|
| | Bank 1,2 | DIMM 1 | DIMM 2 |
| RAM Type | FPM/EDO/BEDO | FPM/EDO/SDRAM | FPM/EDO/SDRAM |
| Single RAM Module Size (MB) | 4/8/16/32/64 | 8/16/32/64/128/256 | 8/16/32/64/128/256 |

- Note:
1. You must install two SIMM modules to complete the SIMM Bank
 2. Do not use FPM or EDO type of SIMM/DIMM if you already use SDRAM.
 3. Do not install SIMM Bank and DIMM 1 at the same time.

Clear CMOS

Clear the CMOS memory by momentarily shorting pin 2-3 on jumper JP5, and then by shorting pin 1-2 to retain new settings. This jumper can be easily identified by its white colored cap.

| CMOS Clearing | Clear CMOS Data | Retain CMOS Data |
|---------------|--|---|
| JP5 Setting | short pin 2-3 to clear the CMOS  | Short pin 1-2 to retain new settings  |

Note: You must unplug the ATX power cable from the ATX power connector when performing the CMOS Clear operation.

3 Quick BIOS Setup

After the hardware installation is complete, turn the power switch on, then press the **** key during the system diagnostic checks to enter the Award BIOS Setup program. The CMOS SETUP UTILITY will display on screen. Then, follow these steps to complete the quick BIOS setup.

Step 1. Select [LOAD SETUP DEFAULT]

Select the "LOAD SETUP DEFAULT" menu and type "Y" at the prompt to load the BIOS optimal setup.

Step 2. Select [STANDARD CMOS SETUP]

Set [Date/Time] and [Floppy drive type], then set [Hard Disk Type] to "Auto".

Step 3. Select [SAVE & EXIT SETUP]


Press **<Enter>** to save the new configuration to the CMOS memory, and continue the boot sequence.

4 The SOYO CD

Your 5EHM/5EH5 Super 7™ Motherboard comes with a CD-ROM labeled "SOYO CD." The SOYO CD contains the user's manual file for your new Motherboard, the drivers software available for installation, and a database in HTML format with information on SOYO Motherboards and other products.

Step 1. Insert the SOYO CD into the CD-ROM drive

The SOYO CD will auto-run, and the SOYO CD Start Up Menu will display as shown below.




(SOYO CD Start Up Program Menu)

The SOYO CD Start Up Program automatically detects which SOYO Motherboard you own and displays the corresponding model name.

Step 2. Read SOYO [5EH] Manual

Click the **Read Manual** button to open the user's manual file of your Motherboard.

Please note that if the Start Up program was unable to determine which SOYO Motherboard you own, the manual selection menu will pop up, as shown below. Then select the user's manual file that corresponds to your Motherboard model name and click **OK**.



(Manual Selection Menu)

The user's manual files included on the SOYO CD are in PDF (Postscript Document) format. In order to read a PDF file, the appropriate Acrobat Reader software must be installed in your system.

Note: The Start Up program automatically detects if the Acrobat Reader utility is already present in your system, and otherwise prompts you on whether or not you want to install it. You must install the Acrobat Reader utility to be able to read the user's manual file. Follow the instructions on your screen during installation, then once the installation is completed, restart your system and re-run the SOYO CD.

Step 3. Installation procedure for Windows 95/98

The following describes the best way of installing Windows 95 or Windows 98 on your 5EHM/5EH5 Motherboard:

- The following BIOS default settings should not be changed:
 1. The 'USB Controller' item under 'Chipset features' is set to enabled.
 2. The 'USB Assigned IRQ' item under 'PnP/PCI Configuration' is set to enabled.

You **MUST** have these two items enabled for Windows 95/98 to run properly on your system.


- Install Windows 95/98

SY-5EHM/5EH5 Quick Start Guide

➤ After installation of windows, you will need to install the ETEQ drivers. Follow the instruction below.

Click the **Install Drivers** button to display the list of drivers that can be installed on your Motherboard. The start-up program displays the drivers available for the 5EHM/5EH5 and the Windows version you use. For Windows 95 four drivers will be listed (see ' Driver Installation Menu' below), for Windows 98 three drivers will be listed (the ACPI drivers will be left out). We recommend you to install all drivers, and to do so in the right sequence (top to bottom).

If you want to see all the drivers available on the SOYO –CD, click the **Display all drivers on the SOYO CD** button. Do NOT install drivers that are not suitable for you board, otherwise your system may crash.



(Driver Installation Menu)

Select which driver you want to install and click **OK**, or click **Cancel** to return to the main menu. When the installation program of a driver starts running the SOYO-CD will exit. After finishing the installation, restart the SOYO-CD and install the next driver.

Note: Once you have selected a driver, the system will automatically exit the SOYO CD to begin the driver installation program. When the installation is complete, most drivers require to restart your system before they can become active.

Step 4. Enter the SOYO CD

Click the **Enter SOYO CD** button to enter the SOYO HTML database. The Start Up program will activate the default HTML browser installed on your system (for example, Internet Explorer or Netscape) to visualize the contents of the SOYO CD.

The SOYO CD contains useful information about your Motherboard and other SOYO products available in as many as eleven different languages. For your convenience, this information is available in HTML format, similar to the format widely used on the Internet.



(SOYO CD HTML Database in English*)

(* The list of menu options may vary between languages)

Note: If no HTML browser is installed on your system, the Start Up program will prompt you on whether or not you would like to install the Internet Explorer* browser. Click YES to install the HTML browser. After the installation is complete, please restart your system. Then re-run the SOYO CD and you will be able to browse the SOYO HTML database.
(* Internet Explorer is a Microsoft Trademark)

SY-5EHM/5EH5 Quick Start Guide

How to contact us:

- If you are interested in our products, please contact the SOYO sales department in the region you live.
- If you require Technical Assistance, please contact our Technical Support in the region you live.

SOYO prefers Email as communication medium, remember to *always add to the email the country that you live in.*

SOYO Taiwan

No. 21 Wu-Kung 5 Rd., Hsin Chuang City, Taipei Hsien, Taiwan

Region Covered: Taiwan and Asia-Pacific. (Including Australia).

Web Site: www.soyo.com.tw

Sales:

Tel: 886-2-22903300-318

Fax: 886-2-22983322

E-mail: salesap@mail.soyo.com.tw

Technical Support:

Fax: 886-2-22983322

E-mail: support@mail.soyo.com.tw

SOYO Europe BV

Signaalrood 19, 2718 SH Zoetermeer The Netherlands

Region Covered: Europe except Germany, Austria and Switzerland

Web Site: www.soyo.nl, www.soyo-europe.com

Sales:

Tel: +31-69-3637500

Fax: +31-79-3637575

Email: sales@soyo.nl

Technical Support:

Tel : +31-79-3637500

Fax: +31-79-3637575

Email: support@soyo.nl

SOYO USA

41484 Christy Street, Fremont, CA 94538

Region Covered: US and Canada

Web Site: www.soyousa.com, www.soyo.com

Sales:

Tel: 510-226-7696

Fax: 510-226-9218

Email : sales@soyosua.com

Technical Support:

Tel: 510-226-7696

Fax: 510-226-9218

Email : support@soyousa.com

SOYO (U.K.) LTD.

Unit 7, Alice Way, Hounslow Business Park, Hanworth Road, Hounslow, TW3 3UD

Region Covered: United Kingdom and Republic of Ireland

Web Site: www.soyo.co.uk

Sales:

Tel : +44 (0)181 569 4111

Fax: +44 (0)181 569 4134

E-mail: sales@soyo.co.uk

Technical Support:

Tel : +44 (0)181 569 4111

Fax: +44 (0)181 569 4134

SY-5EHM/5EH5 Quick Start Guide

E-Mail: support@soyo.co.uk

SOYO Deutschland GmbH

August-Wilhelm-Kuhnholz-Str. 15
D-26135 Oldenburg

Region Covered: Germany, Austria
and Switzerland. (Zuständig für
Deutschland, Österreich, Schweiz)

Web Site: www.saat.de, www.soyo-saat.com, www.soyo-saat.de

Vertrieb Mainboards, Notebooks und
SoyoCom Produkte:

E-Mail: sales@soyo.de

Fon: +49-(0)441/20910-31/33

Fax: +49-(0)441/203422

Technischer Support:

E-Mail: support@soyo.de

Fon: +49-(0)441/20910-40

Fax: +49-(0)441/203422

SOYO KOREA

Region Covered: Korea

Sales:

Tel : 82-2-716-2850

Fax : 82-2-704-2619

E-mail : soyo@soyo.co.kr

Technical Support:

tel : 82-2-717-4392

fax : 82-2-712-5853

e-mail : soyok@chollian.net

SOYO Hong Kong

Region Covered: Hong Kong

Web Site: www.soyo.com.hk

Sales:

tel: 852-27109810

fax: 852-27109078

E-mail: soyo@hkstar.com

Technical Support:

tel: 852-27109810

fax: 852-27109078

E-mail: soyo@hkstar.com

SOYO China (Gin Mei Jei)

Region Covered: All of China

Sales:

Tel: 86-10-62510089

fax: 86-10-62510388

E-mail: soyo@public.bta.net.cn

Technical Support:

Tel: 86-10-62510089

fax: 86-10-62510388

E-mail: soyo@public.bta.net.cn

SOYO Japan

Region Covered: Japan

Web site: www.soyo.co.jp

Sales:

Tel: 81-3-33682188

Fax: 81-3-33682199

E-mail: soyo-jpn@soyo.co.jp

Technical Support:

Tel: 81-3-33682188

Fax: 81-3-33682199

E-mail: support@soyo.co.jp

Edition: July 1999
Version 2.2
SY-5EHM/5EH5
SERIAL

